

Brother Color MFC Toner Reset Instructions

1. With power on, open the toner access main door (You will get a "door open" message in the LCD.)
2. Press the "Clear/Back" button. Go right to the "Toner Reset Menu.
3. Using the up ^ Down > "Search" arrow buttons, you can then scroll through reset options for each of the printer's [4] toner cartridges.
Code: B. = black; C. = cyan; M. = magenta; Y. = yellow
4. For each for these cartridges is the option to reset for low yield = S or High Yield = H.
5. Using the number keypad, select option #1 to reset the size you have installed.
6. Press the "Clear/Back" button to get out of the menu, close door and the problem is solved.
7. If this does not resolve the problem, your toner is probably empty and needs to be replaced. It is hard to determine fullness by feel, as the toner itself is rather light and the cartridge components are heavy.
8. Be sure you are using only the High Yield toners.